



Competition Specialties, Inc.
16936 County Road, 252
McAlpin, Florida 32062
Phone.# 800-226-1274
Tech.# 904-776-1476
Fax.# 904-776-1638
HTTP://WWW.CSICSI.CO

INSTALLATION INSTRUCTIONS FOR SUPER SHIELD P/N #832 CHEVROLET TURBO 400

- 1.) Remove the four top bellhousing bolts and the existing Dipstick Tube.

NOTE:

DUE TO THE VARIOUS VENDERS OF TRANSMISSION CASES, THE CASE TABS ON FRONT-SIDES AND TABS ON BACK-SIDES OF TRANSMISSION MUST BE CUT. GRIND THE TWO RAISED AREAS BESIDE THE TWO CENTER BELLHOUSING BOLTS, ALSO GRIND RAISED AREAS BESIDE THE CENTER BOLTS DOWN APPROXIMATELY 1/16" TO 1/8". THIS MUST BE DONE IN ORDER FOR THE SUPER SHIELD TO FIT PROPERLY OVER THE TRANSMISSION CASE. THE DIPSTICK TUBE MAY NEED TO BE RELOCATED JUST TO THE RIGHT WITH A SMALL BRACKET. THE BOTTOM COOLER LINE MAY REQUIRE A 45 DEGREE FITTING IF USING STOCK STEEL LINES. (THE DIPSTICK TUBE GOES OVER THE SHIELD.)

- 2.) Make sure the bushings are in shield.
- 3.) Install the Super Shield and the metal retainer on the outside of the shield using the four bolts provided. Install retaining bracket with bolts and tighten evenly.
- 4.) Safety-Retainer Belt must go BETWEEN Boss (Back of Shield) and Dipstick tube (See Diagram Below) Trim excess material from belt.

**** **CAUTION** ****
**DO NOT CUT OR
ALTER THIS SHIELD**

